



**SHERWIN  
WILLIAMS.**



101.81

**PROMAR® 200**  
Zero VOC  
Interior Latex Flat

Extra White B30W02651

|                                  |     |                        |
|----------------------------------|-----|------------------------|
| As of 10/26/2016, Complies with: |     |                        |
| OTC                              | Yes | LEED® 09 NC,CI Yes     |
| OTC Phase II                     | Yes | LEED® 09 CS Yes        |
| SCAQMD                           | Yes | LEED® 09 H&S Yes       |
| CARB                             | Yes | LEED® v4 Emissions Yes |
| CARB SCM2007                     | Yes | LEED® v4 VOC Yes       |
| MPI                              | No  |                        |

| <b>CHARACTERISTICS</b>   |   |                 | <b>SPECIFICATIONS</b>   | <b>SURFACE PREPARATION</b> |
|--|---|-----------------|---|----------------------------|
| <b>ProMar 200 Zero VOC Interior Latex Flat</b>   |   |                 | <b>Block</b><br>1ct. PrepRite Block Filler*<br>2cts. ProMar 200 Zero VOC Interior Latex                                     |                            |
| <b>Color:</b>  | Many colors                                       |                 | <b>Drywall</b><br>1ct. ProMar 200 Zero VOC Latex Primer<br>2cts. ProMar 200 Zero VOC Interior Latex                         |                            |
| To optimize hide and color development, always use the recommended P-Shade primer                    |   |                 | <b>Masonry</b><br>1ct. Loxon Concrete & Masonry Primer*<br>2cts. ProMar 200 Zero VOC Interior Latex                         |                            |
| <b>Coverage:</b>   | 350 - 400 sq ft/gal<br>@ 4 mils wet; 1.6 mils dry |                 | <b>Plaster</b><br>1ct. Premium Wall & Wood Primer*<br>2cts. ProMar 200 Zero VOC Interior Latex                              |                            |
| <b>Drying Time, @ 77°F, 50% RH:</b>  |   |                 | <b>Wood</b><br>1ct. Premium Wall & Wood Primer*<br>2cts. ProMar 200 Zero VOC Interior Latex                                 |                            |
| Touch:   | 1 hour  |                 | * These primers contain <50 g/L VOC.  |                            |
| Recoat:  | 4 hours   |                 | Other primers may be appropriate.   |                            |
| Drying and recoat times are temperature, humidity, and film thickness dependent                      |   |                 | When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color. |                            |
| <b>Finish:</b>   | 1.5-3.5 units @ 85°                               |                 |   |                            |
| <b>Flash Point:</b>  | N/A   |                 |   |                            |
| <b>Tinting with CCE only:</b>  |   |                 |   |                            |
| <b>Base</b>  | <b>oz/gal</b>                                     | <b>Strength</b> |   |                            |
| Extra White  | 0-6   | 125%            |   |                            |
| <b>Vehicle Type:</b>   |   | Vinyl Acrylic   |   |                            |
| <b>Extra White B30W02651</b>   |   |                 |   |                            |
| <b>VOC (less exempt solvents):</b>   |   |                 |   |                            |
| <50 g/L; 0.42 lb/gal   |   |                 |   |                            |
| As per 40 CFR 59.406 and SOR/2009-264, s.12  |   |                 |   |                            |
| <b>Volume Solids:</b>  |   | 41 ± 2%         |   |                            |
| <b>Weight Solids:</b>  |   | 57 ± 2%         |   |                            |
| <b>Weight per Gallon:</b>  |   | 11.75 lb        |   |                            |
| <b>WVP Perms (US)</b>  |   | 10.1            |   |                            |
| grains/(hr ft <sup>2</sup> in Hg)  |   |                 |   |                            |
| <b>Anti-microbial</b>  |   |                 |   |                            |
| This product contains agents which inhibit the growth of microbes on the surface of this paint film. |   |                 |   |                            |



**SHERWIN  
WILLIAMS.**

101.81

**PROMAR® 200**  
Zero VOC  
Interior Latex Flat

Extra White B30W02651

| <b><u>SURFACE PREPARATION</u></b>   | <b><u>APPLICATION</u></b>  | <b><u>CAUTIONS</u></b>   |
|---|--|--|
| <b>Plaster</b><br>Bare plaster must be cured and hard. Textured, soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.  | Apply at temperatures above 50°F.<br>No reduction needed.<br><b>Brush</b><br>Use a nylon/polyester brush.<br><b>Roller</b><br>Use a 3/8" - 3/4" nap synthetic cover.<br><b>Spray—Airless</b><br>Pressure ..... 2000 psi<br>Tip ..... .017"- .021"  | For interior use only<br>Protect from freezing.<br>Non-photochemically reactive.<br><br>Before using, carefully read <b>CAUTIONS</b> on label<br><br>HOTW 10/26/2016 B30W02651 29 00<br>FRC, SP, KOR,  |
| <b>Wood</b><br>Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth.   | <b>APPLICATION TIPS</b><br><br>Make sure product is completely agitated (mechanically or manually) before use.<br><br>Priming and application of two coats at the recommended film thickness can help where hiding of a previous coating or application to new drywall is a factor.<br><br>Using the same method of application and batch to touch up with as that originally used will help improve touch up.<br><br>When original application was by spray, preconditioning of touch up paint by running it through the spray tip will help touch up appearance. | <b>CLEANUP INFORMATION</b><br><br>Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.  |
| <b>Mildew</b><br>Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised.<br>Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution. |  |  |
| <b>Caulking</b><br>Gaps between walls, ceilings, crown moldings, and other interior trim can be filled with the appropriate caulk after priming the surface.  |  |  |
|   |  | <p>The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative or visit <a href="http://www.paintdocs.com">www.paintdocs.com</a> to obtain the most current version of the PDS and/or an SDS.</p> |